

INSTALLATION INSTRUCTIONS:

STEP 1- Slide boot over the end of the pipe until tight

STEP 2- Crimp the boot to the pipe

STEP 3- Crimp the boot to the pipe

STEP 4- Crimp the boot to the pipe

TIPS:

Industrial Tape may be used, but we recommend screws.

CAUTION:

Improper installation may result in damage to product or inefficiencies in the system.

