

# BOOTS - UNIVERSAL

## **INSTALLATION INSTRUCTIONS:**

**STEP 1-** Slide boot over pipe until tight

**STEP 2-** L

**STEP 3-** Use 3 sheet metal screws to secure

**STEP 4-**

### **TIPS:**

Industrial Tape may be used, but we recommend screws.

### **CAUTION:**

Improper installation may result in damage to product or inefficiencies in the system.

