

BOOTS - UNIVERSAL

INSTALLATION INSTRUCTIONS:

STEP 1- Slide boot over pipe until tight

STEP 2- L

STEP 3- Use 3 sheet metal screws to secure

STEP 4-

TIPS:

Industrial Tape may be used, but we recommend screws.

CAUTION:

Improper installation may result in damage to product or inefficiencies in the system.

