

INSTALLATION INSTRUCTIONS:

STEP 1- Slide boot over crimped end on pipe.

STEP 2- Rotate boot to be parallel with floor.

STEP 3- Use 3 self tapping sheet metal screws to fasten boot to pipe.

STEP 4- |

TIPS:

Industrial tape can be used, but we recommend using metal screws to install. Rotate boot into position before sliding over pipe.

WARNING!!

Improper installation may result in damage to product or inefficiencies in the system. Use proper PPE and equipment during cutting, bending, and installation processes. Follow local codes and job site safety requirements.

