

## INSTALLATION INSTRUCTIONS:

- 1- Slide rain cap over big end on pipe.
- 2- Rotate rain cap to desired position.
- 3- Use minimum of three 1/2" sheet metal screws to secure rain cap to pipe.

### **NOTE:**

Used for residential applications. Industrial tape, foil, or sealer can be used in addition to sheet metal screws.

### **WARNING!!**

*Improper installation may result in damage to product or inefficiencies in the system. Use proper PPE and equipment during cutting, bending, and installation processes. If local codes differ from these instructions follow local building codes.*

